



AC30V series Pump Control Application

HA502134U001 Issue 3
Technical Manual

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding



ENGINEERING YOUR SUCCESS.

**FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS
CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.**

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalogue and in any other materials provided from Parker Hannifin Corporation or its subsidiaries or authorized distributors.

To the extent that Parker Hannifin Corporation or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

The above disclaimer is being specifically brought to the user's attention and is in addition to and not in substitution to the Exclusions and Limitations on Liability which are set out in the terms and conditions of sale.



Pump Control Application

HA502134U001 Issue 3

© Copyright 2014 Parker Hannifin Manufacturing Limited

All rights strictly reserved. No part of this document may be stored in a retrieval system, or transmitted in any form or by any means to persons not employed by a Parker Hannifin Manufacturing Limited company without written permission from Parker Hannifin Manufacturing Ltd. Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Parker Hannifin Manufacturing Limited cannot accept responsibility for damage, injury, or expenses resulting therefrom.

WARRANTY

Refer to Parker Hannifin Manufacturing Limited Terms and Conditions of Sale. These documents are available on request at www.parker.com.

Parker Hannifin Manufacturing Limited reserves the right to change the content and product specification without notice.

Pump Control Application Manual

Description


The pump application provides either flow control or speed control of a water pump. In AUTO mode a flow feedback transducer is used to close the loop using a PID trim. In MANUAL mode the requested pump speed is derived directly from the flow setpoint. The calculated load is used to detect abnormal behaviour indicating blockage or leakage. Feedback break input detection (4..20mA only).

Features

- Pump application specific menus and parameters
- Flow parameters and diagnostics in L/min
- PID flow control
- Automatic pump blockage and leakage detection (abnormal load)
- Power-up start


Requirements

To use the AC30V for pump control as described in this manual, the application RA502134U001 must be loaded into an AC30V series drive with firmware 1.3.1. or newer.



“Pump Control”

DEDICATED PUMP CONTROL WITH SPECIFIC PUMP FUNCTIONALITY



4 Pump Control Application Manual

Inputs

| Terminal | Function | Comment |
|-------------------|----------------|---|
| ANIN 01 (X11/01) | FLOW FEEDBACK | Flow feedback input (0..10V, 0..20mA, 4..20mA) |
| ANIN 02 (X11/02) | FLOW SETPOINT | Flow setpoint input (0..10V) |
| DIGIN 01 (X13/02) | MANUAL RUN | Drive start with no PID control (speed control) |
| DIGIN 02 (X13/03) | AUTO RUN | Drive start with PID control (flow control) |
| DIGIN 03 (X13/04) | AUTO SELECT | Switch between AUTO and MANUAL modes |
| DIGIN 04 (X12/01) | RUN ENABLE | Auxiliary start signal |
| DIGIN 05 (X12/02) | NOT COAST STOP | Quench drive output |
| DIGIN 07 (X12/04) | | Terminal used as DIGOUT 01 |
| DIGIN 06 (X12/03) | | Terminal used as DIGOUT 02 |

Outputs

| Terminal | Function | Comment |
|-------------------------------|-------------------|---|
| ANOUT 01 (X11/03) | PUMP SPEED DEMAND | Pump speed demand as a percentage of maximum pump speed |
| ANOUT 02 (X11/04) | PUMP LOAD | Estimated load |
| RELAY 01 (X14/01 & X14/02) | RUNNING | When closed the pump is being driven |
| RELAY 02 (X14/03 & X14/04) | NOT TRIPPED | When closed the drive is not tripped |
| DIGOUT 01 (X12/01) | | Terminal used as DIGIN 04 |
| DIGOUT 02 (X12/02) | | Terminal used as DIGIN 05 |
| DIGOUT 03 (X12/03) | LOAD WARNING | Abnormal load (high or low) detection warning (blocked or leaking)) |
| DIGOUT 04 (X12/04) | LOAD FAULT | Abnormal load (high or low) detection fault (blocked or leaking)) |

Graphical Keypad (GKP) Application Customisation

The pump application adds parameters and menus to the GKP. It also modifies the behaviour of the Control Screen and set-up wizard.







| Control Screen | |
|---|-----------------------------------|
| <i>In Remote (terminal or comms) mode</i> | <i>In Local (GKP) mode</i> |
| 1951: Flow Setpoint (L/min) | 1949: Flow Local Setpoint (L/min) |
| 1952: Flow Feedback (L/min) | 1952: Flow Feedback (L/min) |






| Setup Wizard::Application menu |
|---------------------------------|
| 1940: Pump Speed Max (RPM) |
| 1941: Pump Speed Min (RPM) |
| 1942: Pump Displacement(L/rev) |
| 1943: Flow FB Input Max (L/min) |
| 1944: Flow FB Input Min (L/min) |
| 1945: Flow SP Input Max (L/min) |
| 1946: Flow SP Input Min (L/min) |
| 1947: Flow Setpoint Max (L/min) |
| 1948: Flow Setpoint Min (L/min) |
| 1937: Disable Coast Stop |
| 1960: Power Up Start |

| Quick Setup menu |
|---------------------------------|
| 1947: Flow Setpoint Max (L/min) |
| 1948: Flow Setpoint Min (L/min) |
| 1940: Pump Speed Max (RPM) |
| 1941: Pump Speed Min (RPM) |
| 0486: Acceleration Time (s) |
| 0487: Deceleration Time (s) |
| 1928: PID Proportional Gain |
| 1929: PID Integral TC (s) |
| 1934: PID Output Scaling |
| 1932: PID Output Pos Limit (%) |
| 1933: PID Output Neg Limit (%) |
| 1006: Run Setup? |
| 1141: View Level |

6 Pump Control Application Manual

| Quick Monitor menu |
|------------------------------------|
| 1956: Auto Manual State |
| 1997: Load Monitor State |
| 1957: Feedback Input Break |
| 1951: Flow Setpoint (L/min) |
| 1952: Flow Feedback (L/min) |
| 1954: Pump Demand (%) |
| 1955: Actual Load (%) |
| 1953: Flow Remote Setpoint (L/min) |
| 1950: Flow Comms Setpoint (L/min) |
| 1935: PID Output (%) |
| 1936: PID Error (%) |
| 1998: Expected Load (%) |
| 1999: Load Error (%) |

| Setup::Application |
|--|
|  Application |
|  Pump and Flow |
|  Sequencing |
|  PID |
|  Abnormal Load Detect |
|  App Selection |

| Monitor::Application |
|--|
|  Application |
|  Pump and Flow |
|  Sequencing |
|  PID |
|  Abnormal Load Detect |

Pump and Flow

Setup::Application::Pump and Flow
Monitor::Application::Pump and Flow*

Application specific parameters to setup and monitor the pump and flow. All flow parameters are in Litres per minute (L/min).

| PNO | Parameter Descriptions |
|-------------|--|
| <u>1940</u> | <p>Pump Speed Max</p> <p>This is the maximum speed in RPM that the pump can operate. It is the same as the 0464: 100% Speed in RPM parameter.</p> |
| <u>1941</u> | <p>Pump Speed Min</p> <p>This is the minimum speed in RPM that the pump is allowed to operate. It sets the low limit for the speed demand when running.</p> |
| <u>1942</u> | <p>Pump Displacement</p> <p>This parameter sets the number of litres displaced by one revolution of the pump. It is used to convert setpoints and feedbacks given in litres per minute (L/min) to a pump speed in RPM.</p> |
| <u>1943</u> | <p>Flow FB Input Max</p> <p>This is the full range value in L/min for the Flow Feedback analogue input (ANIN01). It corresponds to the maximum input value of either 10V or 20mA depending on the setting of 0001: Anin 01 Type.</p> |
| <u>1944</u> | <p>Flow FB Input Min</p> <p>This is the minimum value in L/min for the Flow Feedback analogue input (ANIN01). It corresponds to the minimum input value of either 0V, 0mA or 4mA depending on the setting of 0001: Anin 01 Type.</p> |
| <u>1945</u> | <p>Flow SP Input Max</p> <p>This is the full range value in L/min for the Flow Setpoint analogue input (ANIN02). It corresponds to the maximum input value of 10V.</p> |
| <u>1946</u> | <p>Flow SP Input Min</p> <p>This is the minimum value in L/min for the Flow Setpoint analogue input (ANIN02). It corresponds to the minimum input value of 0V.</p> |
| <u>1947</u> | <p>Flow Setpoint Max</p> <p>This is the maximum Flow Setpoint that can be set using the GKP, terminals or fieldbus.</p> |
| <u>1948</u> | <p>Flow Setpoint Min</p> <p>This is the minimum Flow Setpoint that can be set using the GKP, terminals or fieldbus.</p> |
| <u>1949</u> | <p>Flow Local Setpoint</p> <p>This is the Local Setpoint in L/min settable using the GKP. It is limited to be between 1947: Flow Setpoint Max and 1948: Flow Setpoint Min, converted to a percentage of the flow rate at 0140: Pump Speed Max and then used to set the 0592: Local Reference parameter.</p> |

8 Pump Control Application Manual

| PNO | Parameter Descriptions |
|-------------|---|
| <u>1950</u> | Flow Comms Setpoint* This is the value of the remote terminal flow setpoint. It is clamped to be between 1947: Flow Setpoint Max and 1948: Flow Setpoint Min . |
| <u>1951</u> | Flow Setpoint* This diagnostic is the value of the active flow setpoint. This will be the same as one of the following: 1953: Flow Remote Setpoint when in remote (terminal) control mode 1950: Flow Comms Setpoint when in comms control mode 1949: Flow Local Setpoint when in local control mode |
| <u>1952</u> | Flow Feedback* This diagnostic is the value of the flow feedback in L/min. It is ANIN1 scaled and offset by 1943: Flow FB Input Max and 1944: Flow FB Input Min . |
| <u>1953</u> | Flow Remote Setpoint* This diagnostic is the value of the remote terminal flow setpoint. It is ANIN2 scaled and offset by 1945: Flow SP Input Max and 1946: Flow SP Input Min , then clamped to be between 1947: Flow Setpoint Max and 1948: Flow Setpoint Min . |
| <u>1954</u> | Pump Demand* This diagnostic is the requested speed of the pump as a percentage of 1940: Pump Speed Max . It is the same as 0500: Ramp Speed Output . |
| <u>1955</u> | Actual load* This diagnostic is the estimated load as a percentage of the maximum load. It is the same as the 0399: Actual Torque parameter which is the calculated torque based on the IQ current. |

Functional Description

The maximum pump speed is set in RPM using the **1940: Pump Speed Max** parameter. This corresponds to 100% speed demand. A minimum speed may be set using the **1940: Pump Speed Min** parameter, also in RPM.

The calculation from flow the pump speed is set by the **0142: Pump Displacement** parameter.

The analog input used for the flow setpoint is scaled using the **1945: Flow SP Input Max** and **1946: Flow SP Input Min** parameters. These define the range and offset in L/min. Similarly, the analog input used for the flow feedback is scaled using the **1947: Flow FB Input Max** and **1948: Flow FB Input Min** parameters.

If not in flow control, the setpoint from either the GKP (1949: Flow Local Setpoint) or the communications (1950: Flow Comms Setpoint) may be used instead of the setpoint from the terminals.

PID

Setup::Application::PID

Monitor::Application::PID*

This function allows the AC30V to be used in applications requiring a trim to the reference, depending on feedback from an external measurement device. Typically this will be used for process control, i.e. pressure or flow.

PNO Parameter Descriptions

Setpoint

This is connected to an Analog Input through the application.

Feedback

This is connected to an Analog Input through the application.

Enable

This is set TRUE by the application when flow control is required (AUTO mode). It globally resets the PID output and integral term when FALSE. **Enable** must be TRUE for the PID to operate.

1928

PID Proportional Gain

This is the true proportional gain of the PID controller. When set to zero the PID Output is zero.

1929

PID Integral TC

The integral time constant of the PID controller.

1930

PID Derivative TC

The derivative time constant of the PID controller.

10 Pump Control Application Manual

PNO Parameter Descriptions

1931 PID Output Filter TC

In order to help attenuate high frequency noise on the PID output, a first order output filter has been provided. This parameter determines the output filter time constant.

1932 PID Output Pos Limit

The maximum positive excursion (limit) of the PID output.

1933 PID Output Neg Limit

The maximum negative excursion (limit) of the PID output.

1934 PID Output Scaling

The overall scaling factor which is applied after the positive and negative limit clamps


1935 PID Output*

PID output monitor

1936 PID Error*

PID error monitor. This is Setpoint – Feedback.

Functional Description



Abnormal Load Detect

Setup::Application::Abnormal Load Detect
Monitor::Application::Abnormal Load Detect*

When used in the Pump Control Application this feature is used to detect high load low load indicating blockage and low load indicating leakage.

| PNO | Parameter Descriptions |
|-------------|---|
| <u>1968</u> | Enable Load Monitor Set TRUE to enable this feature. |
| <u>1969</u> | Startup Delay This sets the duration from when the motor is started until the load monitoring is started. This allows for inaccurate speed/load characterisation and load estimation during start-up period. |
| <u>1970</u> | Fault Delay This sets the duration from when the load monitor detects a LOAD FAULT until the sequencers stops the motor. This allows for inaccurate speed/load characterisation and load estimation during start-up period. |
| <u>1971</u> | High Fault Level This specifies the deviation of the actual load above the expected load which will cause a LOAD HIGH FAULT to be reported. |
| <u>1972</u> | High Warning Level This specifies the deviation of the actual load above the expected load which will cause a LOAD HIGH WARNING to be reported. |
| <u>1973</u> | Low Warning Level This specifies the deviation of the actual load below the expected load which will cause a LOAD LOW WARNING to be reported. |
| <u>1974</u> | Low Fault Level This specifies the deviation of the actual load below the expected load which will cause a LOAD LOW FAULT to be reported. |
| <u>1976</u> | Speed 1 |
| <u>1977</u> | Speed 2 |
| <u>1978</u> | Speed 3 |
| <u>1979</u> | Speed 4 |
| <u>1980</u> | Speed 5 |
| <u>1981</u> | Speed 6 |
| <u>1982</u> | Speed 7 |
| <u>1983</u> | Speed 8 |
| <u>1984</u> | Speed 9 |
| <u>1985</u> | Speed 10 |

These 10 parameters specify together with the 10 Load parameters below are used to characterise the expected load 'curve' for the actual Speed.

12 Pump Control Application Manual

| PNO | Parameter Descriptions |
|-------------|---|
| <u>1987</u> | Load 1 |
| <u>1988</u> | Load 2 |
| <u>1989</u> | Load 3 |
| <u>1990</u> | Load 4 |
| <u>1991</u> | Load 5 |
| <u>1992</u> | Load 6 |
| <u>1993</u> | Load 7 |
| <u>1994</u> | Load 8 |
| <u>1995</u> | Load 9 |
| <u>1997</u> | Load 10 |
| | See above Speed parameters. |
| <u>1997</u> | Load Monitor State* |
| | This diagnostic reports whether the monitor is monitoring and, if so, if the Load is as expected. This is an enumerated value: |
| 0 | MONITORING DISABLED Either Enable Load Monitor is FALSE or Speed 1 = 0.0%. |
| 1 | MONITORING STOPPED Motor not running, so not monitoring. |
| 2 | MONITORING STARTING Motor started less than Startup Delay ago, so not monitoring yet. |
| 3 | LOAD NORMAL The actual Load is within the expected range, so anomaly detected. |
| 4 | LOAD HIGH WARNING The actual Load is above the High Warning Level but not higher than the High Fault Level . |
| 5 | LOAD LOW WARNING The actual Load is below the Low Warning Level but not lower than the Low Fault Level . |
| 6 | LOAD HIGH FAULT The actual Load is above the High Fault Level . |
| 7 | LOAD LOW FAULT The actual Load is below the Low Fault Level . |
| <u>1998</u> | Expected Load* |
| | This diagnostic is the calculated Load expected for the current Speed. This is determined from the load 'curve' specified by the Speed n and Load n parameters and is useful for checking that in the case of incorrect warning or fault reporting. |
| <u>1999</u> | Load Error* |
| | This diagnostic is difference between Actual Load and Expected Load . |


Functional Description

An estimate of the expected Load for any given Speed is specified using the **Speed n** and **Load n** parameters. Each pair provide a point on the expected Load line.

The Speed parameters must have increasing values. I.e. **Speed 1 < Speed 2 < Speed 3 < Speed 4 < Speed 5 < Speed 6 < Speed 7 < Speed 8 < Speed 9 < Speed 10**.

If not all points are required, a Speed may be set to zero to terminate the sequence. If the actual speed is greater than the last specified point, the line is extrapolated from the previous 2 points.

Speed 1 must be non-zero, otherwise the abnormal load detection feature is disabled.



Offset from the expected Load line, 4 additional lines are calculated. These are the Warning and Fault detection thresholds. The deviation from normal behavior is determined by the **High Fault Level**, **High Warning Level**, **Low Warning Level** and **Low Fault Level** parameters.

When running, the **Load Monitor State** diagnostic will show if the actual Load is in the NORMAL, WARNING or FAULT regions of the graph. Note – for this to report correctly, the **High Fault Level** must be more positive than the **High Warning Level** and the **Low Fault Level** must be more negative than the **Low Warning Level**.

If the actual Load remains in a FAULT region for longer than the duration specified by **Fault Delay**, the Drive will stop running.

The **Start Delay** may be used to prevent incorrect warning or fault reports soon after the Run command is issued.

The **Load Monitor State** diagnostic is reset when the Run command is removed.

14 Pump Control Application Manual

Sequencing

Setup::Application::Sequencing
Monitor::Application::Sequencing

The Pump Control Application introduces these additional sequencing parameters.

| PNO | Parameter Descriptions |
|-------------|---|
| <u>1937</u> | Disable Coast Stop When TRUE, the default for this parameter, the COAST STOP input is ignored. |
| <u>1960</u> | Power Up Start When TRUE the Drive will immediately run on power up if the AUTO RUN or MANUAL RUN digital input is TRUE. If this parameter is FALSE (the default) a FALSE to TRUE transition of the RUN input is required. |
| <u>1956</u> | Auto Manual State* This diagnostic reports whether the drive is AUTO or MANUAL mode and the running state of the Pump. 0 MANUAL DISABLED 1 MANUAL STOPPED 2 MANUAL RUNNING Pump running in speed control 3 MANUAL STOPPING 4 AUTO DISABLED 5 AUTO STOPPED 6 AUTO RUNNING Pump running in flow control 7 AUTO STOPPING |
| <u>1957</u> | Feedback Input Break* This diagnostic is TRUE when the flow feedback analogue input is not working. Flow control will not operate. |

Functional Description

Disable Coast Stop:

This feature disables the use of the COAST STOP input.



Caution The Drive will not stop when the coast stop input is disconnected.

Power Up Start:

This feature removes the requirement of a transition from FALSE to TRUE on the run command. This allows an immediate start of the motor when power is applied to the Drive.



Caution The Drive may run without warning.

16 Pump Control Application Manual

PARAMETER TABLE

| PNO | Name | Path(s) | Type | Default | Range | Units | WQ | Modbus |
|------|-----------------------|-------------------------------------|------|---------|-----------------|-------|---------|--------|
| 1928 | PID Proportional Gain | Setup::Application::PID | REAL | 1.0 | 0.0 to 100.0 | | ALWAYS | 04383 |
| 1929 | PID Integral TC | Setup::Application::PID | TIME | 1.00 | 0.01 to 100.00 | s | ALWAYS | 04385 |
| 1930 | PID Derivative TC | Setup::Application::PID | TIME | 0.000 | 0.000 to 10.000 | s | ALWAYS | 04387 |
| 1931 | PID Output Filter TC | Setup::Application::PID | TIME | 0.1 | 0.000 to 10.000 | s | ALWAYS | 04389 |
| 1932 | PID Output Pos Limit | Setup::Application::PID | REAL | 100.00 | 0.00 to 105.00 | % | ALWAYS | 04391 |
| 1933 | PID Output Neg Limit | Setup::Application::PID | REAL | -100.00 | -105.00 to 0.00 | % | ALWAYS | 04393 |
| 1934 | PID Output Scaling | Setup::Application::PID | REAL | 1.00 | -10.00 to 10.00 | | ALWAYS | 04395 |
| 1935 | PID Output | Monitor::Application::PID | REAL | 0.00 | | % | NEVER | 04397 |
| 1936 | PID Error | Monitor::Application::PID | REAL | 0.00 | | % | NEVER | 04399 |
| 1937 | Disable Coast Stop | Setup::Application::Sequencing | BOOL | TRUE | | | STOPPED | 04401 |
| 1940 | Pump Speed Max | Setup::Application::Pump and Flow | REAL | 100.0 | 1.0 to 10000.0 | L/min | STOPPED | 04407 |
| 1941 | Pump Speed Min | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | STOPPED | 04409 |
| 1942 | Pump Displacement | Setup::Application::Pump and Flow | REAL | 1.00 | 0.01 to 1000.00 | L/rev | STOPPED | 04411 |
| 1943 | Flow FB Input Max | Setup::Application::Pump and Flow | REAL | 100.0 | 1.0 to 10000.0 | L/min | STOPPED | 04413 |
| 1944 | Flow FB Input Min | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | STOPPED | 04415 |
| 1945 | Flow SP Input Max | Setup::Application::Pump and Flow | REAL | 100.0 | 1.0 to 10000.0 | L/min | STOPPED | 04417 |
| 1946 | Flow SP Input Min | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | STOPPED | 04419 |
| 1947 | Flow Setpoint Max | Setup::Application::Pump and Flow | REAL | 100.0 | 1.0 to 10000.0 | L/min | STOPPED | 04421 |
| 1948 | Flow Setpoint Min | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | STOPPED | 04423 |
| 1949 | Flow Local Setpoint | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | % | ALWAYS | 04425 |
| 1950 | Flow Comms Setpoint | Setup::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | % | ALWAYS | 04427 |
| 1951 | Flow Setpoint | Monitor::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | NEVER | 04429 |
| 1952 | Flow Feedback | Monitor::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | NEVER | 04431 |
| 1953 | Flow Remote Setpoint | Monitor::Application::Pump and Flow | REAL | 0.0 | 0.0 to 10000.0 | L/min | NEVER | 04433 |
| 1954 | Pump Demand | Monitor::Application::Pump and Flow | REAL | 0.0 | 0.0 to 100.0 | % | NEVER | 04435 |
| 1955 | Actual Load | Monitor::Application::Pump and Flow | REAL | 0.0 | 0.0 to 100.0 | % | NEVER | 04437 |

| PNO | Name | Path(s) | Type | Default | Range | Units | WQ | Modbus |
|------|----------------------|--|-----------------|---------|--|-------|--------|--------|
| 1956 | Auto Manual State | Monitor::Application::Sequencing | USINT (enum) | 0 | 0: MANUAL DISABLED 1: MANUAL STOPPED 2: MANUAL RUNNING 3: MANUAL STOPPING 4: AUTO DISABLED 5: AUTO STOPPED 6: AUTO RUNNING 7: AUTO STOPPING | | NEVER | 04439 |
| 1957 | Feedback Input Break | Monitor::Application::Sequencing | BOOL | FALSE | | | NEVER | 04441 |
| 1960 | Power Up Start | Setup::Application::Sequencing | BOOL | FALSE | | | ALWAYS | 04447 |
| 1968 | Enable Load Monitor | Setup::Application::Abnormal Load Detect | BOOL | 0 | | | ALWAYS | 04463 |
| 1969 | Startup Delay | Setup::Application::Abnormal Load Detect | TIME | 10 | | s | ALWAYS | 04465 |
| 1970 | Fault Delay | Setup::Application::Abnormal Load Detect | TIME | 1 | | s | ALWAYS | 04467 |
| 1971 | High Fault Level | Setup::Application::Abnormal Load Detect | REAL | 100.0 | 0.0 to 100.0 | % | ALWAYS | 04469 |
| 1972 | High Warning Level | Setup::Application::Abnormal Load Detect | REAL | 100.0 | 0.0 to 100.0 | % | ALWAYS | 04471 |
| 1973 | Low Warning Level | Setup::Application::Abnormal Load Detect | REAL | -100.0 | -100.0 to 0.0 | % | ALWAYS | 04473 |
| 1974 | Low Fault Level | Setup::Application::Abnormal Load Detect | REAL | -100.0 | -100.0 to 0.0 | % | ALWAYS | 04475 |
| 1976 | Speed 1 | Setup::Application::Abnormal Load Detect | REAL | 0.0 | 0.0 to 100.0 | % | ALWAYS | 04479 |
| 1977 | Speed 2 | | | | | | | 04481 |
| 1978 | Speed 3 | | | | | | | 04483 |
| 1979 | Speed 4 | | | | | | | 04485 |
| 1980 | Speed 5 | | | | | | | 04487 |
| 1981 | Speed 6 | | | | | | | 04489 |
| 1982 | Speed 7 | | | | | | | 04491 |
| 1983 | Speed 8 | | | | | | | 04493 |
| 1984 | Speed 9 | | | | | | | 04495 |
| 1985 | Speed 10 | | | | | | | 04497 |
| 1987 | Load 1 | Setup::Application::Abnormal Load Detect | REAL | 0.0 | 0.0 to 100.0 | % | ALWAYS | 04501 |
| 1988 | Load 2 | | | | | | | 04503 |
| 1989 | Load 3 | | | | | | | 04505 |
| 1990 | Load 4 | | | | | | | 04507 |

18 Pump Control Application Manual

| PNO | Name | Path(s) | Type | Default | Range | Units | WQ | Modbus |
|------|-----------------------|--|-----------------|---------|---|-------|--------|--------|
| 1991 | Load 5 | | | | | | | 04509 |
| 1992 | Load 6 | | | | | | | 04511 |
| 1993 | Load 7 | | | | | | | 04513 |
| 1994 | Load 8 | | | | | | | 04515 |
| 1995 | Load 9 | | | | | | | 04517 |
| 1996 | Load 10 | | | | | | | 04519 |
| 1997 | Load Monitoring State | Monitor::Application::Abnormal Load Detect | USINT (enum) | 0 | 0: MONITORING DISABLED 1: MONITORING STOPPED 2: MONITORING STARTING 3: LOAD NORMAL 4: LOAD HIGH WARNING 5: LOAD LOW WARNING 6: LOAD HIGH FAULT 7: LOAD LOW FAULT | | ALWAYS | 04521 |
| 1998 | Expected Load | Monitor::Application::Abnormal Load Detect | REAL | 0.0 | 0.0 to 100.0 | % | NEVER | 04523 |
| 1999 | Load Error | Monitor::Application::Abnormal Load Detect | REAL | 0.0 | -400.0 to 400.0 | % | NEVER | 04525 |

Parker Worldwide

AE – UAE, Dubai

Tel: +971 4 8127100

parker.me@parker.com

AR – Argentina, Buenos Aires

Tel: +54 3327 44 4129

AT – Austria, Wiener Neustadt

Tel: +43 (0)2622 23501-0

parker.austria@parker.com

AT – Eastern Europe, Wiener Neustadt

Tel: +43 (0)2622 23501 900

parker.easteurope@parker.com

AU – Australia, Castle Hill

Tel: +61 (0)2-9634 7777

AZ – Azerbaijan, Baku

Tel: +994 50 2233 458

parker.azerbaijan@parker.com

BE/LU – Belgium, Nivelles

Tel: +32 (0)67 280 900

parker.belgium@parker.com

BR – Brazil, Cachoeirinha RS

Tel: +55 51 3470 9144

BY – Belarus, Minsk

Tel: +375 17 209 9399

parker.belarus@parker.com

CA – Canada, Milton, Ontario

Tel: +1 905 693 3000

CH – Switzerland, Etoy

Tel: +41 (0)21 821 87 00

parker.switzerland@parker.com

CL – Chile, Santiago

Tel: +56 2 623 1216

CN – China, Shanghai

Tel: +86 21 2899 5000

CZ – Czech Republic, Klecany

Tel: +420 284 083 111

parker.czechrepublic@parker.com

DE – Germany, Kaarst

Tel: +49 (0)2131 4016 0

parker.germany@parker.com

DK – Denmark, Ballerup

Tel: +45 43 56 04 00

parker.denmark@parker.com

ES – Spain, Madrid

Tel: +34 902 330 001

parker.spain@parker.com

FI – Finland, Vantaa

Tel: +358 (0)20 753 2500

parker.finland@parker.com

FR – France, Contamine s/Arve

Tel: +33 (0)4 50 25 80 25

parker.france@parker.com

GR – Greece, Athens

Tel: +30 210 933 6450

parker.greece@parker.com

HK – Hong Kong

Tel: +852 2428 8008

HU – Hungary, Budapest

Tel: +36 1 220 4155

parker.hungary@parker.com

IE – Ireland, Dublin

Tel: +353 (0)1 466 6370

parker.ireland@parker.com

IN – India, Mumbai

Tel: +91 22 6513 7081-85

IT – Italy, Corsico (MI)

Tel: +39 02 45 19 21

parker.italy@parker.com

JP – Japan, Tokyo

Tel: +81 (0)3 6408 3901

KR – South Korea, Seoul

Tel: +82 2 559 0400

KZ – Kazakhstan, Almaty

Tel: +7 7272 505 800

parker.easteurope@parker.com

MX – Mexico, Apodaca

Tel: +52 81 8156 6000

MY – Malaysia, Shah Alam

Tel: +60 3 7849 0800

NL – The Netherlands, Oldenzaal

Tel: +31 (0)541 585 000

parker.nl@parker.com

NO – Norway, Asker

Tel: +47 66 75 34 00

parker.norway@parker.com

NZ – New Zealand, Mt Wellington

Tel: +64 9 574 1744

PL – Poland, Warsaw

Tel: +48 (0)22 573 24 00

parker.poland@parker.com

PT – Portugal, Leca da Palmeira

Tel: +351 22 999 7360

parker.portugal@parker.com

RO – Romania, Bucharest

Tel: +40 21 252 1382

parker.romania@parker.com

RU – Russia, Moscow

Tel: +7 495 645-2156

parker.russia@parker.com

SE – Sweden, Spånga

Tel: +46 (0)8 59 79 50 00

parker.sweden@parker.com

SG – Singapore

Tel: +65 6887 6300

SK – Slovakia, Banská Bystrica

Tel: +421 484 162 252

parker.slovakia@parker.com

SL – Slovenia, Novo Mesto

Tel: +386 7 337 6650

parker.slovenia@parker.com

TH – Thailand, Bangkok

Tel: +662 717 8140

TR – Turkey, Istanbul

Tel: +90 216 4997081

parker.turkey@parker.com

TW – Taiwan, Taipei

Tel: +886 2 2298 8987

UA – Ukraine, Kiev

Tel: +380 44 494 2731

parker.ukraine@parker.com

UK – United Kingdom, Warwick

Tel: +44 (0)1926 317 878

parker.uk@parker.com

US – USA, Cleveland

Tel: +1 216 896 3000

VE – Venezuela, Caracas

Tel: +58 212 238 5422

ZA – South Africa, Kempton Park

Tel: +27 (0)11 961 0700

parker.southafrica@parker.com

European Product Information Centre**Free phone: 00 800 27 27 5374****(from AT, BE, CH, CZ, DE, EE, ES, FI, FR, IE, IL, IS, IT,****LU, MT, NL, NO, PT, SE, SK, UK)****Parker Hannifin Manufacturing Limited
Automation Group, SSD Drives Europe,**

New Courtwick Lane,

Littlehampton, West Sussex. BN17 7RZ

Office: +44 (0)1903 737000

Fax: +44 (0)1903 737100

www.parker.com/ssd



* H A 5 0 2 1 3 4 U 0 0 1 0 3 *