

Hydraulic Pumps - Overall Instructions T7 / T67 / T6 Double

Denison Vane Technology, fixed displacement

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding



ENGINEERING YOUR SUCCESS.

Table of contents

1 . START-UP INSTRUCTIONS & RECOMMENDATIONS	
1 . 1 . General & start-up check-up	3
1 . 2 . Shaft & coupling data	4
1 . 3 . Specific points	4
1 . 4 . Fluids	5
2 . PUMP & CARTRIDGE BREAKDOWN DRAWING	6
3 . CONVERSIONS	
3 . 1 . Complete disassembly of the pump	7 to 12
3 . 2 . Changing rotation.....	13 to 16
3 . 3 . Complete reassembly of the pump	17 to 21
3 . 4 . Changing porting P1	22 to 24
3 . 5 . Changing portings P2 & P3	25 to 26
4 . KEY SHEET, TORQUES & PORTING TABLES	
4 . 1 . Key sheet	27
4 . 2 . Torque requirements	27
4 . 3 . Porting tables	28
5 . SPECIAL TOOLS	
5 . 1 . Seal driver - Dimensions	29
5 . 2 . Protective cone - Dimensions	29 to 30
6 . COUPLINGS	
6 . 1 . Female coupling dimensions	31
7 . VANE TROUBLESHOOTING GUIDE	32 to 35



WARNING – USER RESPONSIBILITY

FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

This document and other information from Parker-Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

Offer of Sale

Please contact your Parker representation for a detailed "Offer of Sale".

1.1. GENERAL :

All Parker vane pumps are individually tested to provide the best quality & reliability. Modifications, conversions & repairs can only be done by authorized dealers or OEM to avoid invalidation of the guarantee.

The pumps are to be used within the design limits indicated in all the sales bulletins. Please contact Parker when trespassing the catalogue limits.

Do not modify or work on the pump under pressure or when the electric motor (or any drive) is on.

Qualified personnel is required to assemble and set-up hydraulic devices.

Always conform yourself to the valid regulations (safety, electrical, environment...).

The following instructions are important to obtain a good service life time from the unit.

ROTATION & PORTS INDICATION

The rotation and ports orientation are viewed from the shaft end.

R = CW stands for clockwise = right-hand rotation.

L = CCW stands for counter-clockwise = left-hand rotation.

START-UP & CHECK-UP**Check that the assembly of the power unit is correct :**

The distance between the suction pipe & the return lines in the tank should be at its maximum.

A bevel on both suction & return lines is recommended to increase the surface and so lower the velocity. We suggest a 45° minimum angle.

Velocities : inlet $0,5 < x < 1,9$ m/s (1,64 < x < 6,23 ft per sec.)
 : return $x < 6$ m/s (x < 19,7 ft per sec.)
 : Always insure that all return and suction lines are under the oil level to avoid forming aeration or vortex effect. This should be done under the most critical situation (all cylinders extended for example). Straight and short pipes are the best.

$$V = \frac{Q \text{ (Lpm)}}{6 \times \pi \times r^2 \text{ (cm)}} = \text{m/s} \quad V = \frac{Q \text{ (GPM)}}{3.12 \times \pi \times r^2 \text{ (in)}} = \text{ft/s}$$

The size of the air filter should be 3 times greater than the max. instant return flow (all cylinders in movement for example).

If the pump is in the tank, please choose the NOP option (no paint) and use a short inlet pipe.

Parker does not recommend inlet strainers. If needed, a 100 mesh (149 microns) is the finest mesh recommended.

A coaxial drive is recommended. For any other type of drives, please contact Parker.

Make sure that all protective plugs & covers have been removed.

Check the pump rotation versus the E-motor or engine rotation.

Start-up : The tank has been filled up with a clean fluid in proper conditions.

We recommend to flush the system with an external pump prior to the start-up.

It is important to bleed the air off the circuit and the pump itself.

The first valve on the circuit should be open to tank.

We recommend the use of air bleed off valves.

It is possible to bleed off the air by creating a leak in the P port of the pump. **Warning : this has to be done in a low pressure mode as it could create a dangerous fluid leak. Make sure that the pressure cannot rise (open center valve to tank, pressure relief valve unloaded ...).**

When oil free of air appears, tighten the connectors to the correct torque.

The pump should prime within a few seconds. If not, please consult our troubleshooting guide (page 33).

If the pump is noisy, please troubleshoot the system.

Never operate the pump at top speed and pressure without checking the completion of pump priming.

1.2. SHAFT & COUPLING DATA : COUPLINGS AND FEMALE SPLINES

- The mating female spline should be free to float and find its own center. If both members are rigidly supported, they must be aligned within 0,15 TIR (0.006" TIR) or less to reduce fretting. The angular alignment of two splines axes must be less than $\pm 0,05$ per 25,4 radius (± 0.002 " per 1" radius).
- The coupling spline must be lubricated with a lithium molydisulfide grease, disulfide of molybdenum or a similar lubricant.
- The coupling must be hardened to a hardness between 29 and 45 HRC.
- The female spline must be made to conform to the Class 1 fit as described in SAE-J498b (1971). This is described as a Flat Root Side Fit.

KEYED SHAFTS

Parker supplies the T7 series keyed shaft pumps with high strength heat-treated keys. Therefore, when installing or replacing these pumps, the heat-treated keys must be used in order to ensure maximum life in the application. If the key is replaced, it must be a heat-treated key between 27 and 34 R.C. hardness. The corners of the keys must be chamfered by 0,76 mm to 1,02 mm (0.03 to 0.04) at 45° to clear the radii in the key way.

The alignment of keyed shafts must be within tolerances given for splined shafts here above.

SHAFT LOADS

These products are primarily designed for coaxial drives which do not impose axial or side loading on the shaft. Contact Parker for specific applications.

1.3. SPECIFIC POINTS : MINIMUM INLET PRESSURE

Please read the charts in the sales leaflets as the minimum requested inlet pressure varies versus the displacement and the speed. Never go under 0,8 bar Absolute (-0,2 bar relative)
11.6 PSI Absolute (-2.9 PSI G).

MAXIMUM INLET PRESSURE

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet. Standard shaft seals are limited to 0,7 bar (10 PSI G) but some allow 7 bar (100 PSI G). Please contact Parker for more information.

MINIMUM OUTLET PRESSURE

It is recommended to always have at least 1,5 bar (22 PSI) differential between inlet and outlet.

VERTICAL MOUNT

When assembled vertically, always be careful to prevent any air from being trapped in the pump (behind the shaft seal for example).



1.4. FLUIDS :**DENISON CLASSIFICATION**

Type of fluids : For each type of fluids, Parker vane pumps will products have different pressures, speeds & temperature limits. Please refer to the sales leaflets.

HF-0 = Anti-wear petroleum base.

HF-1 = Non anti-wear petroleum base.

HF-2 = Anti-wear petroleum base.

HF-3 = Water-in-oil invert emulsions.

HF-4 = Water glycol solutions.

HF-5 = Synthetic fluids.

FILTRATION RECOMMENDATIONS

NAS 1638 class 8 or better.

ISO 19/17/14 or better.

Inlet strainers : Parker does not recommend inlet strainers.

If requested, a 100 mesh (149 microns) is the finest mesh recommended.

RECOMMENDED FLUIDS

Petroleum based antiwear R & O fluids.

These fluids are the recommended fluids for pumps & motors. Maximum catalogue ratings and performance datas are based on operation with these fluids. These fluids are covered by Parker Denison HF-0 and HF-2 specifications.

ACCEPTABLE ALTERNATE FLUIDS

The use of fluids other than petroleum based antiwear R & O fluids requires that the maximum ratings of the pumps will be reduced. In some cases the minimum replenishment pressures must be increased. Consult specific sections for more details (page 4).

VISCOSITY

	Mobile	Industrial
Max. (cold start, low speed & pressure)		
	2000 cSt - 9400 SUS	860 cSt - 3900 SUS
Max. (full speed & pressure)		
	108 cSt - 500 SUS	108 cSt - 500 SUS
Optimum (max. life)	30 cSt - 140 SUS	30 cSt - 140 SUS
Min. (full speed & pressure for HF-1, HF-3, HF-4 & HF-5 fluids)		
	18 cSt - 90 SUS	18 cSt - 90 SUS
Min. (full speed & pressure for HF-0 & HF-2 fluids)		
	10 cSt - 60 SUS	10 cSt - 60 SUS

VISCOSITY INDEX

90 min. Higher values extend the range of operating temperatures.

TEMPERATURE

The usual limiting factor of temperature (low or high) comes from the obtained viscosity. The seals are sometimes the limit : standard seals range from -30° C (-9.4° F to 194° F).

Maximum fluid temperature (θ)	° C	° F
HF-0, HF-1, HF-2	+ 100	+ 212
HF-3, HF-4	+ 50	+ 122
HF-5	+ 70	+ 158
Biodegradable fluids (esters & rapeseed base)		
	+ 65	+ 149


Minimum fluid temperature (θ) (also depend on max. viscosity)	° C	° F
HF-0, HF-1, HF-2, HF-5	- 18	- 0.4
HF-3, HF-4	+ 10	+ 50
Biodegradable fluids (esters & rapeseed base)		
	- 18	- 0.4

Over or under these values, please contact Parker.

WATER CONTAMINATION IN THE FLUID


Maximum acceptable content of water :

- 0,10 % for mineral base fluids.
 - 0,05 % for synthetic fluids, crankcase oils, biodegradable fluids.
- If the amount of water is higher, then it must be drained off the circuit.




3 . 1 . COMPLETE DISASSEMBLY OF THE PUMP :

1 . Install the pump on the table.




Two bolts will help to unscrew the 4 pumps bolts.

2 . Unbolt the screws.




3.1. COMPLETE DISASSEMBLY OF THE PUMP :

3 . Remove the end cap
(P2 cartridge will come
with it).




Cartridge : be careful as
some items could fall if
the retaining cartridge
bolts are totally loose or
broken.



The seal usually stays in
the rear cap.

3.1. COMPLETE DISASSEMBLY OF THE PUMP :

4 . Disassemble the P2 cartridge / end cap with an extractor.




If you want to continue the pump disassembly (P2 & shaft), go to next page.



If you want to reassemble the P2 cartridge, go to page 17.

5 . Put two screws in the housing and flip the pump (housing + P1 ass'y).




If you want to convert P2, go to page 13.

3.1. COMPLETE DISASSEMBLY OF THE PUMP :


6 . Remove the screws.




For all pumps except :
T6EES / T7EES
T6DDS / T7DDS



For pumps :
T6EES / T7EES
T6DDS / T7DDS



7 . Remove the front cap.



P1 cartridge will come
with the front cap / shaft
assembly.



3.1. COMPLETE DISASSEMBLY OF THE PUMP :

8 . Disassemble the P1 cartridge / front cap with an extractor.

If you wish to convert the cartridge, go to page 13.

A : Remove the retaining ring.

B : Extract the shaft / bearing assembly.




Take a protection cone to prevent seal damage (dim. page 30).
If you don't, change the shaft seal.

If not new, the shaft seal should be replaced.

If the shaft \varnothing is bigger than the shaft seal \varnothing , please contact Parker (TPI).





3.1 . COMPLETE DISASSEMBLY OF THE PUMP :

9 . Shaft seal out.



3.2. CHANGING ROTATION :**1 . Explanations :**

Bi & uni-rotational port plates.


Bi-rotational port plate**Uni-rotational port plate****Bi-rotational port plate****Uni-rotational port plate**

3.2. CHANGING ROTATION :


It is possible to change the rotation if the port plates are bi-rotational.

If uni-rotational, change the port plates to change the rotation.

2 . Remove the two retaining screws.



3 . Remove the rear port plate.



Rear port plate with or without bushing, it depends :
P2 position = no bushing.
P3 position = with bushing.




Same parts could sticks to the port plate.

3.2. CHANGING ROTATION :


Push all the vanes inside the rotor to avoid any damage of it.

Position the cam ring.



3.2. CHANGING ROTATION :

6 . Position the dowel pin.

7 . Position the port plate
& screws.


Before tightening the screws, rotate the rotor/vane.

Retaining screws = assembly purpose & concentricity of the elements.

Rotate rotor after cartridge assembly.

The screws should only be loosely tightened.


Try to assemble all the elements as cylindrically as possible.

**GOOD
CONCENTRICITY****BAD
CONCENTRICITY**


If the elements are not properly assembled together (bad concentricity), the cartridge will not fit correctly into the housing.

3.3. COMPLETE REASSEMBLY OF THE PUMP :

- 1 . Fit the cartridge (P1) into the housing.



- 2 . Check if the dowel pin is in its position in the housing by trying to rotate the cartridge.



If the cartridge does rotate, the dowel pin is not in the hole. Take the cartridge out and try again.


3.3. COMPLETE REASSEMBLY OF THE PUMP :


A : Protective cone on the shaft assembly (dim. per shaft in page 30).

B : Shaft assembly + protective cone into the front cap. Slightly rotate the shaft to avoid the shaft seal lip(s) to be deteriorated.

C : Retaining ring into the front cap.

3. Assemble the front cap assy on the housing & cartridge assy.




3.3. COMPLETE REASSEMBLY OF THE PUMP :

a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 28).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.

TORQUE REQUIREMENTS :


Pump		Nm	ft.lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P - T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S - T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & End cap	190	140
T6ED/M/P - T7ED/S	Mounting cap & End cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

d) Always check if the shaft rotates.

If not, disassemble and go back to the previous step.

3.3 . COMPLETE REASSEMBLY OF THE PUMP :

4 . Fit the cartridge (P2)
into the housing.




5 . Check if the dowel pin
is in its position in the
housing by trying to
rotate the cartridge.



If the cartridge does rotate, the dowel pin is not in the hole. Take the cartridge out and try again.

6 . Assemble the end
cap on the housing
assy.



Position the shaft / front cap assy only if the cartridge is well positioned, dowel pin in the housing dowel pin hole.

Put some grease on the seals to prevent them from moving.


If the cartridge is blocked at "1/2 parcours", rotate the shaft.



Always check if the shaft rotates freely. If not, disassemble and go back to the previous step.

3.3. COMPLETE REASSEMBLY OF THE PUMP :


7 . Final assy.



a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table pages 28).

c) Tighten the 4 or 7 screws.



Step by step to avoid
damaging the seals.

d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

TORQUE REQUIREMENTS :

Pump		Nm	ft.lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P - T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S - T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & End cap	190	140
T6ED/M/P - T7ED/S	Mounting cap & End cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

3.4. CHANGING PORTING - P1 :**P1 porting**


1. Install the pump on the table.

Two bolts in the front cap will help unscrew 2 of the 4 opposite pump bolts.


2. Unscrews the 4 bolts.



For all pumps except :
T6EES / T7EES
T6DDS / T7DDS



For pumps :
T6EES / T7EES
T6DDS / T7DDS




3 . 4 . CHANGING PORTING - P1 :**P1 porting**

3 . Flip the pump upside-down.

4 . Unscrew the 4 bolts.

5 . Keep two bolts.

6 . Rotate the housing with a bar blocked between the two screws.

 don't lift or move the housing.


Note : the cartridge will rotate with the housing.




For all pumps except :
T6EES / T7EES
T6DDS / T7DDS



For pumps :
T6EES / T7EES
T6DDS / T7DDS



Metallic bar



Metallic bar

3.4. CHANGING PORTING - P1 :

P1 porting


7 . Put the screws back.



For all pumps except :
T6EES / T7EES
T6DDS / T7DDS




For pumps :
T6EES / T7EES
T6DDS / T7DDS



a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.

b) Check the porting configuration (see table page 28).

c) Tighten the 4 screws.



Step by step to avoid damaging the seals.

TORQUE REQUIREMENTS :


Pump		Nm	ft.lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P - T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S - T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & End cap	190	140
T6ED/M/P - T7ED/S	Mounting cap & End cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

d) Always check if the shaft rotates. If not, disassemble and go back to the previous step.

3.5. CHANGING PORTING - P2 :**P2 porting**

- 1 . Install the pump on the table.


Insert 2 bolts in the front cap to prevent the pump from moving.




- 2 . Unscrew the 4 of 7 bolts.

- 3 . Keep two bolts.

- 4 . Rotate the end cap with a bar blocked between the two screws.


 don't lift or move the housing.

Note : the cartridge will rotate with the housing.




3.5. CHANGING PORTINGS - P2 :

9 . Put the 4 or 7 screws back.



- a) Always check if the shaft rotates. (a slight torque due to the spring loaded resistance force). Otherwise, please go back to the previous step.
- b) Check the porting configuration (see table pages 28).
- c) Tighten the 4 or 7 screws.



Step by step to avoid damaging the seals.

TORQUE REQUIREMENTS :

Pump		Nm	ft.lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P - T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S - T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & End cap	190	140
T6ED/M/P - T7ED/S	Mounting cap & End cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

- d) Always check if the shaft rotates.
If not, disassemble and go back to the previous step.

4.1. KEY SHEET**Model No.****T67DC W - B42 - 010 - 1 R 00 - A 1 M1 - ..****Series** - SAE C 2 bolts

J744 mounting flange

P1

P2

Modifications**Severe duty shaft option****Mounting w/connection variables**

4 bolts SAE flanges J518

Displacement P1

Volumetric displacement (ml/rev.)

B14 = 44,0

B31 = 99,2

B17 = 55,0

B35 = 113,4

B20 = 66,0

B38 = 120,6

B22 = 70,3

B42 = 137,5

B24 = 81,1

045 = 145,7

B28 = 90,0

050 = 158,0

Displacement P2

Volumetric displacement (ml/rev.)

003 = 10,8

017 = 58,3

005 = 17,2

020 = 63,8

006 = 21,3

022 = 70,3

008 = 26,4

025 = 79,3

010 = 34,1

028 = 88,8

012 = 37,1

031 = 100,0

014 = 46,0

Type of shaft

1 = keyed (SAE C)

3 = splined (SAE C) 14 teeth

2 = keyed (non SAE)

4 = splined (spec. SAE C)

Type of shaft - Severe duty (T67DCW only)

5 = keyed (non SAE)

	Metric thread		UNC thread	
	M0	M1	00	01
P1	1.1/4"	1.1/4"	1.1/4"	1.1/4"
P2	1"	3/4"	1"	3/4"
S	3"	3"	3"	3"

Seal class

1 = S1 BUNA N - 0,7 bar max. (for mineral oil)
 4 = S4 EPDM - 7 bar max. (for fire resistant fluids)
 5 = S5 VITON® - 7 bar max. (for mineral oil and fire resistant fluids)

Design letter**Porting combination**

00 = standard

Direction of rotation (shaft end view)

R = Clockwise

L = Counter-clockwise

4.2. TORQUE REQUIREMENTS :

Pump		Nm	ft.lbs
T7BB/S	Housing	187	138
	End cap	61	45
T6CC/M/P - T67CB	Mounting cap	159	117
	End cap	61	45
T7DB/S - T6DC/M/P T67DC - T7EB/S T6EC/M/P - T67EC/M/P	Mounting cap	187	138
	End cap	68	50
T6DD/S - T7DD/S	Housing & End cap	190	140
T6ED/M/P - T7ED/S	Mounting cap & End cap	187	138
T6EE/S - T7EE/S	Cover	88	65
	End cap & Housing	300	221

Porting tables**Overall Hydraulic Double Vane Pumps
Series T7 - T67 - T6, Denison Vane Pumps****4.3. PORTING TABLES :**

T7BB/T7BBS

T6CC

T67CB

T7DB/T7DBS

T67DC

T7EB/T7EBS

T67EC

00 P1-P2	01 P1-P2	02 S-P1-P2	03 P1-P2	04 P1	05 P1	06 P1	07 P1-S
08 P1-S	09 P1-S	10 P1	11 P1	12 P1	13 P1	14 P1	15 P1
16 P1	17 P1	18 P1	19 P1	20 P1	21 P1	22 P1	23 P1
24 P1-S	25 P1-S	26 P1-S	27 P1-S	28 P1	29 P1	30 P1	31 P1

T7DD/T7DDS


T7ED/T7EDS

T7EE/T7EES

00 P1-P2	01 P1-P2	02 S-P1-P2	03 P1-P2	04 P1	05 P1	06 P1	07 P1-S
08 P1-S	09 P1-S	10 P1	11 P1	12 P1	13 P1	14 P1	15 P1

5.1. SEAL DRIVER - DIMENSIONS :

Series	Tool n°	Ø A		Ø B		C	
		mm	inch	mm	inch	mm	inch
T67CB - T6CC/M/P	DM3-418S0-1	25,27 25,40	0.995 1.000	37,82 37,98	1.489 1.495	145	5.708
T7DB/S - T67DB T6DC/M/P - T67DC	DM3-418S0-2	34,74 34,90	1.368 1.374	56,92 57,11	2.241 2.248	145	5.708
T6DDS - T7DD/S T7EB/S - T6EC/M/P - T67EC T6ED/M/P - T7ED/S	DM3-418S0-4	41,11 41,27	1.618 1.625	59,97 60,16	2.361 2.368	145	5.708
T6GCC	DM3-418S1-3	44,00 44,10	1.732 1.736	61,71 61,90	2.429 2.437	70	2.756
T6EE - T7EE/S	DM3-418S1-6	47,90 47,95	1.886 1.888	61,75 61,85	2.431 2.435	145	5.708
T7BB/S	DM3-418S1-0	31,60 31,75	1.244 1.250	44,16 44,32	1.738 1.745	145	5.708




Notes :

1. Remove all burrs and break sharp edges : 0,25/0,13 R (.010/.005 R).
2. Length $\triangle 2$ to be heat treated to 47 + 3 HRC.
3. Length $\triangle 2$ to have a $\sqrt[10-20]{}$ full length, with a smooth intersection between chamfer and dia "A".
4. Grease O.D. of length $\triangle 2$ before installing the shaft seal on the tool to avoid damaging the seal. Material US 4140 / UK 708 M40 or equivalent.

5.2. PROTECTIVE CONE - DIMENSIONS :

Series	Code n°	Tool n°	A		Ø B		Ø C	
			mm	inch	mm	inch	mm	inch
T6CC	1	DM3-392CP-01	70,0	2.756	25.30 25.40	0.996 1.000	22.28 22.35	0.877 0.880
	2	DM3-392CP-15	70,0	2.756	31.77 31.72	1.251 1.249	25.43 25.51	1.001 1.004
	5	DM3-392CP-33	38,0	1.496	25.30 25.40	0.996 1.000	21.86 21.81	0.859 0.861
T6CCP	3	DM3-392CP-17	36,0	1.417	31.77 31.72	1.251 1.249	21.85 21.93	0.860 0.863
T6CCM	5	DM3-392CP-25	45,0	1.771	25.45 25.35	1.002 0.998	20.98 21.05	0.826 0.829



Notes :


1. Remove all burrs and break sharp edges: 0.25/0.13 R (.010/.005 R).
2. Teflon preferred, alternate 4140 treated after machining to RC 50-55.
3. Install protective cone over shaft extension and grease O.D. to prevent damaging the shaft seal.



If shaft Ø > than shaft seal Ø, there are not specific tools. Please contact Parker for the specific TPI.

5.2. PROTECTIVE CONE - DIMENSIONS :

Series	Code n°	Tool n°	A		Ø B		Ø C	
			mm	inch	mm	inch	mm	inch
T7BBS	1	DM3-392CP-05	70,0	2.756	31,77 31,72	1.251 1.249	22,28 22,35	0.877 0.880
	3	DM3-392CP-17	36,0	1.417			21,85 21,93	0.860 0.863
	4	DM3-392CP-41	45,0	1.771			25,02 25,07	0.985 0.987
T7BB	5	DM3-392CP-19	68,0	2.677			25,03 25,13	0.985 0.989
T67CB	1	DM3-392CP-01	70,0	2.756	25,30 25,40	0.996 1.000	22,28 22,35	0.877 0.880
	2	DM3-392CP-15	70,0	2.756	31,77 31,72	1.251 1.249	25,43 25,51	1.001 1.004
	5	DM3-392CP-25	45,0	1.771	25,45 25,35	1.002 0.998	20,98 21,05	0.826 0.829
T7DB/S T6DC T67DC	1 & 2	DM3-392CP-02	83,0	3.268	34,95 35,00	1.376 1.378	31,80 31,88	1.252 1.255
	3 4	DM3-392CP-14	60,0	2.362			31,25 31,33	1.230 1.233
	5	DM3-392CP-16	80,0	3.150	41,25 41,33	1.624 1.627	34,95 35,03	1.376 1.379
T6DDS T7DD/S	1	DM3-392CP-11	80,0	3.150	41,25 41,33	1.624 1.627	31,80 31,88	1.252 1.255
	2	DM3-392CP-04	89,0	3.504			38,15 38,23	1.502 1.505
	3	DM3-392CP-10	55,0	2.165			31,25 31,33	1.230 1.233
	4	DM3-392CP-39	50,0	1.968			25,05 25,13	0.986 0.989
	5	DM3-392CP-24	93,0	3.661			34,92 35,00	1.375 1.378
T7EB/S T6EC T67EC T7ED/S	1	DM3-392CP-04	89,0	3.504	41,25 41,33	1.624 1.627	38,15 38,23	1.502 1.505
	2	DM3-392CP-11	80,0	3.150			31,80 31,88	1.252 1.255
	3	DM3-392CP-10	55,0	2.165			31,25 31,33	1.230 1.233
	4	DM3-392CP-12	60,0	2.362			37,60 37,68	1.480 1.483
T6EE T7EE/S	1	DM3-392CP-37	85,0	3.346	47,95 48,00	1.888 1.890	38,15 38,23	1.502 1.505
	2	DM3-392CP-26	90,0	3.543			45,03 45,06	1.773 1.774
	3	DM3-392CP-38	56,0	2.205	39,95 40,00	1.573 1.575	37,60 37,70	1.480 1.484
	4	DM3-392CP-27	72,0	2.835	47,95 48,00	1.888 1.890	43,72 43,80	1.721 1.724
	5	DM3-392CP-34	96,0	3.779			44,50 44,60	1.752 1.756




Notes :


1. Remove all burrs and break sharp edges: 0.25/0.13 R (.010/.005 R).
2. Teflon preferred, alternate 4140 treated after machining to RC 50-55.
3. Install protective cone over shaft extension and grease O.D. to prevent damaging the shaft seal.



If shaft Ø > than shaft seal Ø, there are not specific tools. Please contact Parker for the specific TPI.

6.1. FEMALE COUPLING DIMENSIONS :**SPLINED SHAFTS :**

Shafts	T7BBS code 3 T67CB code 5 T6CC* code 5		T7BBS code 4 T67CB code 3 T6CC* code 3 T7DD code 4		T7DB code 3 & 4 T67DC code 3 & 4 T6DC* code 3 & 4 T7DD code 3 T7EB code 3 T6EC* code 3 T67EC code 3 T6ED* code 3 T7ED code 3		T7EB code 4 T6EC* code 4 T67EC code 4 T6ED* code 4 T7ED code 4 T6EE* code 3 T7EE code 3		T6EE* code 4 T7EE code 4	
Type	SAE B		SAE BB		SAE C		SAE CC		SAE D & E	
Number of teeth	13		15		14		17		13	
Pitch	16/32		16/32		12/24		12/24		8/16	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Major dia.	22,221	0.8748	25,400	1.0000	31,750	1.2500	38,100	1.5000	44,450	1.7500
	22,500	0.8858	25,679	1.0110	32,080	1.2630	38,430	1.5130	44,907	1.7680
Minor dia.	19,134	0.7533	22,268	0.8767	27,589	1.0862	33,876	1.3337	38,237	1.5054
	19,261	0.7583	22,395	0.8817	27,716	1.0912	34,003	1.3387	38,364	1.5104
Pitch dia.	20,638	0.8125	23,812	0.9375	29,634	1.1667	35,984	1.4167	41,275	1.625
Form dia.	21,908	0.8625	25,082	0.9875	31,326	1.2333	37,676	1.4833	43,815	1.7289
Pin dia.	2,743	0.1080	2,743	0.1080	3,658	0.1440	3,658	0.1440	5,486	0.2160
Max. measurement between two pins	16,505	0.6498	19,722	0.7765	24,305	0.9569	30,562	1.2032	32,940	1.2969
	16,589	0.6531	19,807	0.7798	24,407	0.9609	30,648	1.2066	33,055	1.3014
Circular space width :										
Min. effective	2,494	0.0982	2,494	0.0982	3,325	0.1309	3,325	0.1309	4,986	0.1963
Max. actual	2,560	0.1008	2,560	0.1008	3,398	0.1338	3,401	0.1339	5,065	0.1994
Radius max.	0,150	0.0059	0,150	0.0059	0,300	0.0118	0,300	0.0118	0,350	0.0138

KEYED SHAFTS :

Shafts	T7BB code 1 T67CB code 1 T6CC* code 1		T7BB code 5		T7BB code 2 T67CB code 2 T6CC* code 2	
	mm	inch	mm	inch	mm	inch
Diameter	22,232	0.8753	25,007	0.9845	25,409	1.0004
	22,253	0.8761	25,028	0.9854	25,434	1.0013
W	4,792	0.1887	8,040	0.3165	6,390	0.2516
	4,840	0.1906	8,098	0.3188	6,448	0.2539
B	24,50	0.9646	28,22	1.1110	28,22	1.1110
	24,83	0.9776	28,55	1.1240	28,55	1.1240

Shafts	T7DB code 1 & 2 T6DC* code 1 & 2 T67DC code 1 & 2 T7DD code 1 T7EB code 2 T6EC* code 2 T67EC code 2 T6ED* code 2 T7ED code 2		T7DB code 5 T7DD code 5		T6DC* code 5 T67DC code 5		T7EB code 5 T7ED code 5		T7DD code 2 T7EB code 1 T6EC* code 1 T67EC code 1 T6ED* code 1 T7ED code 1 T6EE* code 1 T7EE code 1		T6EE* code 2 T7EE* code 2		T6EE* code 5 T7EE code 5	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Diameter	31,759	1.2504	32,025	1.2608	34,909	1.3744	38,025	1.4970	38,109	1.5004	45,009	1.7720	44,459	1.7504
	31,784	1.2513	32,050	1.2618	34,934	1.3754	38,050	1.4980	38,134	1.5013	45,034	1.7730	44,484	1.7513
W	7,980	0.3142	10,040	0.3953	7,980	0.3142	10,040	0.3953	9,560	0.3764	14,050	0.5531	11,160	0.4394
	8,038	0.3165	10,098	0.3976	8,038	0.3165	10,098	0.3976	9,618	0.3787	14,120	0.5559	11,230	0.4421
B	35,27	1.3886	35,27	1.3886	38,42	1.5131	41,30	1.6260	42,36	1.6677	48,50	1.9094	49,30	1.9409
	35,66	1.4039	35,66	1.4039	38,81	1.5280	41,69	1.6413	42,75	1.6831	48,89	1.9248	49,69	1.9563

7 . VANE TROUBLESHOOTING GUIDE :

1 . No flow, no pressure	a) Is the pump rotating ?	a-1) Check if the coupling is rotating. If not, check the rotation of the electric motor. a-2) Check the keys of the pump and E motor shaft. a-3) Check if the shaft is not broken.
	b) Is the rotation in the correct direction?	b-1) Check if the rotation of the pump corresponds to the arrow on the name plate. b-2) Check if the wiring of the electric motor is correct.
	c) Is the air bleed-off done?	c-1) Check that no air is still located in the pressure line. Loosen a connector.
	d) How are the inlet conditions?	d-1) Check if the inlet gate valve is not closed. d-2) Check the oil level. d-3) Check if the inlet hose in the tank is under the oil tank level. d-4) Check if an air intake is not disturbing the inlet (missing inlet flange seal, air trapped in suction line as examples). d-5) Check if the pump is not located too high above the oil level. d-6) Check if the tank is not completely sealed. Then the lack of atmospheric pressure will not allow the pump to prime. d-7) Check if all connections and seals are air-tight.
	e) Is the Viscosity not too high?	e-1) Check if the oil characteristics are not incompatible with the temperature and the pumps requirements. Too high Viscosity will "stick" the vein fluid and enable the pump to suck the oil correctly.
	f) Is the pump flow not going somewhere else?	f-1) Check the hydraulic circuit and the main sequences. Doing so, you will check if all the valves are set or work properly. f-2) Check if the main relief valve is not set at an extremely low pressure and therefore bringing all the flow back to the tank. f-3) Check if in the directional valves the spools are not sticking in a position that brings the flow back to the tank. f-4) check if the check valve is not mounted «upside down».
	g) Is the receptor working correctly?	g-1) Check if the motor does not let all the flow leak internally. g-2) Check if the cylinder inner seals are not ruined.
	h) Is the speed high enough?	h-1) Check if the minimum speed is reached. Mobile pumps require 400 rpm and industrial pumps require 600 rpm.
2 . Not enough flow (or not the flow required)	a) Are the components OK?	a-1) Check the displacement of the pump. a-2) Check if the speed of the pump is not too low or too high (E motor or thermic engine sized too small so dropping the speed too low...) a-3) Check if the main relief valve is not set at an extremely low pressure and therefore venting some flow back to the tank.

7 . VANE TROUBLESHOOTING GUIDE :

2 . Not enough flow (or not the flow required) (continuation)	a) Are the components OK ? (continuation)	<p>a-4) Check if in the directional valves the spools are not sticking in a position that brings part of the flow back to the tank.</p> <p>a-5) Check if the hydraulic motor is not leaking internally due to a bad efficiency, low viscosity...</p> <p>a-6) Check if the cylinder inner seals are not ruined and therefore allow internal leakage.</p>
	b) Is the connection from the tank to the pump correct ?	<p>b-1) Check if there is no air intake between the pump and the inlet pipe (bad seals for example).</p> <p>b-2) Check if the inlet hose is convenient for the required velocity ($0,5 < V < 1,9$ m/s).</p> <p>b-3) Check if the pump is not too high compared to the oil level or if the pump is not too far from the tank (check the inlet absolute pressure with the catalog values).</p> <p>b-4) Check if the gate valve is not semi-open.</p> <p>b-5) Check if the inlet strainer is sized correctly (250 m mesh mini.) or not clogged.</p>
	c) Is the tank design correct ?	<p>c-1) Check if the oil level is correct.</p> <p>c-2) Check if the suction pipe is under the oil level during the complete cycle of the machine.</p> <p>c-3) Check if the inlet hose fitted in the tank is cut with an angle wider than 45°.</p> <p>c-4) Check if this inlet hose is not too close to the tank wall or to the bottom of the tank and therefore limits the "vein flow".</p> <p>c-5) Check if the suction hose is not located near the return line and therefore sucking a lot of air coming from these turbulences.</p> <p>c-6) Check if baffles are required to allow correct deaeration of the fluid.</p> <p>c-7) Check if the air filter is not clogged or undersized (not well dimensioned).</p> <p>c-8) Check if the tank is not fully tight, not allowing the atmospheric pressure to apply.</p>
	d) Is the oil convenient ?	<p>d-1) Check if the oil characteristics are not incompatible with the pumps requirements.</p> <p>d-2) Check if the viscosity is not too high, therefore «sticking» some vanes in the rotor or blocking the vein fluid.</p> <p>d-3) Check if the high temperature does not destroy the viscosity of the fluid. Doing so, the internal leakage will «consume» the flow.</p>
3 . No pressure	a) Is the hydraulic circuit correctly designed ?	a-1) Check the hydraulic circuit schematic.
	b) Is the circuit correctly piped ?	b-1) Compare the schematic to the piped circuit.

7 . VANE TROUBLESHOOTING GUIDE :

3 . No pressure (continuation)	c) Are the components working properly ?	<p>c-1) Check the main sequences. Doing so, you will check if all the valves are set or work properly.</p> <p>c-2) Check if the main relief valve is not set at an extremely low pressure and therefore bringing all the flow back to the tank.</p> <p>c-3) Check if in the directional valves the spools are not sticking in a position that brings the flow back to the tank.</p>
4 . Not enough pressure	a) Check as when "no pressure" 3.	
	b) Is the system well dimensioned ?	b-1) Check if the flow required is not over the available flow and therefore cannot build-up pressure.
	c) Is there an internal leakage somewhere that maintains a certain pressure ?	c-1) Check all the possible faulty components, from the pump to all the receptors and intermediates (high pressure seals, mechanical wear...).
5 . Uncommon noise level	a) Is the noise coming from the pump ?	<p>a-1) Check the mechanical link of the pump shaft : alignment, balancing of the coupling or Universal joint, key properly fastened...</p> <p>a-2) Check if the air bleed has been done correctly.</p> <p>a-3) Check if there is no air intake from the tank to the pump (nor through the shaft seal).</p> <p>a-4) Check if the hose strain force does not create this noise.</p> <p>a-5) Check if the oil level is correct.</p> <p>a-6) Check if the oil in the tank is not aerated.</p> <p>a-7) Check if the strainer is not clogged or under-dimensioned.</p> <p>a-8) Check if the inlet pipe is under the oil level.</p> <p>a-9) Check if the air filter is not clogged or too small.</p> <p>a-10) Check if the speed is not incompatible with the catalog values.</p> <p>a-11) Check if the oil is compatible with the catalog recommendations.</p> <p>a-12) Check if the inlet pressure is not higher than the outlet pressure.</p>
	b) Is the noise coming from the surroundings ?	<p>b-1) Check the hoses and see if the noise is not coming back to the pump this way.</p> <p>b-2) Check the pressure piping and see if its length damps or amplifies the noise.</p> <p>b-3) Check if the structure of the tank is stiff enough to avoid amplification / resonance.</p> <p>b-4) Check the E motor fan.</p> <p>b-5) Check the balancing of the E motor.</p> <p>b-6) Check the water cooler and its theoretical limits.</p> <p>b-7) Check the filtration unit, its capacity and if the noise does not come from the opened by-pass valve.</p>

7 . VANE TROUBLESHOOTING GUIDE :

6 . Unusual heat level	<p>a) Does the heat appear when the pump is running without pressure?</p> <p>b) Does the heat appear when the pump is running with pressure?</p>	<p>a-1) Check the oil level and the suction pipe. Is the oil coming to the pump (check the length of the pipe, its internal diameter, all that could influence the inlet pressure)?</p> <p>a-2) Check if the air bleed has been done correctly.</p> <p>a-3) Check if the flow versus the volume of oil in the tank is correct to obtain a good cooling effect.</p> <p>a-4) Check if a cooler is required or, if there is one, if it is well dimensioned.</p> <p>a-5) If there is a cooler, check if it is working (example for water cooler: is the water flow open or sufficient).</p> <p>a-6) Check if the hydraulic circuit is not bringing back the flow directly to the inlet port. Doing so, it would create a very small closed circuit not able to cool down the fluid.</p> <p>a-7) Check the quality of the fluid.</p> <p>a-8) Check the velocity of the fluid.</p> <p>a-9) Check the filtration unit, its capacity and if the heat does not come from the open by-pass valve or if it is under-dimensioned (bigger delta P).</p> <p>b-1) Check the viscosity.</p> <p>b-2) Check the pressure rating.</p> <p>b-3) Check if the cooler is working correctly or well dimensioned.</p> <p>b-4) Check if the relief valve is not creating this heat because always open.</p> <p>b-5) Check if any other component in the system is not creating this heat due to an internal defect.</p> <p>b-6) Check if there is a big temperature differential between the inlet and the outlet.</p>
7 . Shaft seal leakage	<p>a) Is the seal destroyed?</p> <p>b) Is the seal only leaking?</p>	<p>a-1) Check the alignment and the correct power transmission (non homokinetic movement, high radial force as examples).</p> <p>a-2) Check the inlet pressure and compare it to the catalog values.</p> <p>a-3) Check if the bad suction conditions do not create a vacuum that could even reverse the seal lip.</p> <p>a-4) Check if the external environment is not too dirty and therefore ruining the seal.</p> <p>b-1) Check the alignment of the front shaft and check if there is not any radial load.</p> <p>b-2) Check if seal lip has not been cut during a maintenance operation.</p> <p>b-3) Check if the inlet pressure is not over or under the catalog values. This has to be done for the whole cycle because the inlet pressure can vary from time to time.</p> <p>b-4) Check if the seal material has not been modified because of a too warm environment. The seal can vulcanize and stop sealing correctly.</p> <p>b-5) Check the acidity of the oil that can «burn» the seals material. It will therefore destroy the elasticity of the sealing.</p> <p>b-6) Check if the chosen seal (high pressure seal for example) is not too stiff for the use. If the environment requires some elasticity due to a gentle misalignment, a high pressure seal will not be able to follow the movement and therefore leak.</p>

Parker Worldwide

Europe, Middle East, Africa

AE – United Arab Emirates,
Dubai

Tel: +971 4 8127100
parker.me@parker.com

AT – Austria, Wiener Neustadt

Tel: +43 (0)2622 23501-0
parker.austria@parker.com

AT – Eastern Europe, Wiener
Neustadt

Tel: +43 (0)2622 23501 900
parker.easteurope@parker.com

AZ – Azerbaijan, Baku

Tel: +994 12 47 73 799
parker.azerbaijan@parker.com

BE/LU – Belgium, Nivelles

Tel: +32 (0)67 280 900
parker.belgium@parker.com

BY – Belarus, Minsk

Tel: +375 17 209 9399
parker.belarus@parker.com

CH – Switzerland, Etoy

Tel: +41 (0)21 821 87 00
parker.switzerland@parker.com

CZ – Czech Republic, Klecany

Tel: +420 284 083 111
parker.czechrepublic@parker.com

DE – Germany, Kaarst

Tel: +49 (0)2131 4016 0
parker.germany@parker.com

DK – Denmark, Ballerup

Tel: +45 43 56 04 00
parker.denmark@parker.com

ES – Spain, Madrid

Tel: +34 902 330 001
parker.spain@parker.com

FI – Finland, Vantaa

Tel: +358 (0)20 753 2500
parker.finland@parker.com

FR – France, Contamine s/Arve

Tel: +33 (0)4 50 25 80 25
parker.france@parker.com

GR – Greece, Athens

Tel: +30 210 933 6450
parker.greece@parker.com

HU – Hungary, Budaoers

Tel: +36 23 885 470
parker.hungary@parker.com

IE – Ireland, Dublin

Tel: +353 (0)1 466 6370
parker.ireland@parker.com

IT – Italy, Corsico (MI)

Tel: +39 02 45 19 21
parker.italy@parker.com

KZ – Kazakhstan, Almaty

Tel: +7 7273 561 000
parker.easteurope@parker.com

NL – The Netherlands, Oldenzaal

Tel: +31 (0)541 585 000
parker.nl@parker.com

NO – Norway, Asker

Tel: +47 66 75 34 00
parker.norway@parker.com

PL – Poland, Warsaw

Tel: +48 (0)22 573 24 00
parker.poland@parker.com

PT – Portugal, Leca da Palmeira

Tel: +351 22 999 7360
parker.portugal@parker.com

RO – Romania, Bucharest

Tel: +40 21 252 1382
parker.romania@parker.com

RU – Russia, Moscow

Tel: +7 495 645-2156
parker.russia@parker.com

SE – Sweden, Spånga

Tel: +46 (0)8 59 79 50 00
parker.sweden@parker.com

SK – Slovakia, Banská Bystrica

Tel: +421 484 162 252
parker.slovakia@parker.com

SL – Slovenia, Novo Mesto

Tel: +386 7 337 6650
parker.slovenia@parker.com

TR – Turkey, Istanbul

Tel: +90 216 4997081
parker.turkey@parker.com

UA – Ukraine, Kiev

Tel: +380 44 494 2731
parker.ukraine@parker.com

UK – United Kingdom, Warwick

Tel: +44 (0)1926 317 878
parker.uk@parker.com

ZA – South Africa, Kempton Park

Tel: +27 (0)11 961 0700
parker.southafrica@parker.com

North America

CA – Canada, Milton, Ontario

Tel: +1 905 693 3000

US – USA, Cleveland

(industrial)
Tel: +1 216 896 3000

US – USA, Elk Grove Village

(mobile)
Tel: +1 847 258 6200

Asia Pacific

AU – Australia, Castle Hill

Tel: +61 (0)2-9634 7777

CN – China, Shanghai

Tel: +86 21 2899 5000

HK – Hong Kong

Tel: +852 2428 8008

IN – India, Mumbai

Tel: +91 22 6513 7081-85

JP – Japan, Fujisawa

Tel: +81 (0)4 6635 3050

KR – South Korea, Seoul

Tel: +82 2 559 0400

MY – Malaysia, Shah Alam

Tel: +60 3 7849 0800

NZ – New Zealand, Mt Wellington

Tel: +64 9 574 1744

SG – Singapore

Tel: +65 6887 6300

TH – Thailand, Bangkok

Tel: +662 717 8140

TW – Taiwan, Taipei

Tel: +886 2 2298 8987

South America

AR – Argentina, Buenos Aires

Tel: +54 3327 44 4129

BR – Brazil, Cachoeirinha RS

Tel: +55 51 3470 9144

CL – Chile, Santiago

Tel: +56 2 623 1216

MX – Mexico, Apodaca

Tel: +52 81 8156 6000

Ed. 2012-06-19

EMEA Product Information Centre

Free phone: 00 800 27 27 5374

(from AT, BE, CH, CZ, DE, DK, EE, ES, FI, FR, IE, IL,
IS, IT, LU, MT, NL, NO, PL, PT, RU, SE, SK, UK, ZA)

US Product Information Centre

Toll-free number: 1-800-27 27 537

www.parker.com

Your local authorized Parker distributor

