


# IQAN-TOC8

External power (max 6 Amp)



for use with IQANsimulate only

\* Note: for systems that operate four or more outputs simultaneously, connect supply using BAT and BAT2 pins and 30A fuse.



ENGINEERING YOUR SUCCESS

Electrical schematic IQAN-TOC8

Publ.no: HY17-8304-ES1/UK  
Ed: 07/2008

Information in this document is subject to change without notice