Thermostatic Expansion Valve

for Replacement of Adjustable Bottom Cap Assemblies or for Converting Non-Adjustable Valves to Adjustable Type

Installation Instructions

- Before disassembling the TEV, be sure the refrigerant pressure in the system has been reduced to a safe level (0 psig).
- 2. If the valve is non-adjustable, remove non-adjustable bottom cap and spring guide and discard both parts. If the valve is adjustable, remove seal cap, bottom cap assembly, and spring guide (if applicable) and discard these parts.
- 3. Install new spring guide (if applicable), adjustable bottom cap assembly and seal cap furnished with kit. Adjustable bottom assemblies for Types A, BBI, BF, BQ, CBBI, CBI, EBF, EBQ, EF, EQ, F, FB, K, M, Q, RC, SBF, SBQ, SQ, V and W thermostatic expansion valves use a non-rising stem construction, and the spring guide is an integral part of the assembly. Refer to exploded views on the back of this sheet.

Note: Replacing internal parts on expansion valves can be quite difficult if these valves have been installed on their side, i.e., the bottom cap is neither above nor below the valve's thermostatic element (power head).

4. With the system operating, check the superheat, (see enclosed Temperature-Pressure card), and adjust the valve if necessary. Install and tighten seal cap, this cap is the primary seal.



© COPYRIGHT 2000 BY SPORLAN VALVE COMPANY, WASHINGTON, MO

PRINTED IN THE U.S. OF A. SD-24-2-100

Valve Adjustment for Bottom Cap Assemblies





KA-2 for Valve Type D **KA-3** for Valve Types H, P

KA-8 for Valve Types C, EBS, (E)G, (E)MC, S

KA-5X for Valve Type X*



PIN & CARRIER



SPRING



SPRING GUIDE



BOTTOM CAP GASKET (D Only)




BOTTOM ADJUSTMENT ASSEMBLY



SEAL CAP GASKET (D, H, P)



KA-4 for Valve Types BBI*, (E)BF, (E)BQ, (E)F, (E)Q, FB, SBF, SBQ, SQ KA-Y1132 for Valve Types CBBI*, CBI, RC



KA-1 for Valve Type A **KA-6** for Valve Types K,
M, V

KA-7 for Valve Type W

SPRING (or Outer Spring on A, K, M or V)



** INNER SPRING (A, K, M or V)

BOTTOM CAP GASKET



BOTTOM ADJUSTMENT ASSEMBLY

SEAL CAP GASKET



SEAL CAP



** May or may not be present, depending upon thermostatic charge used with valve.

* For straight through connections ONLY