



S3C Valve Module Quick Reference Guide

SD-437 / 82017

Controller v. A



The Sporlan **S3C Valve Module** should be installed only by a qualified professional. All other system components should be supplied by Sporlan to ensure compatibility and proper operation. The S3C Valve Module fully integrates with the Sporlan S3C Case Control System. NOTE: This S3C Valve Module Quick Reference Guide assumes the S3C Case Controller has been set-up prior to installation of the S3C Valve Module. See 100-50-9.1 for full set-up instructions.



Use caution when working around high voltage components. Safety covers should be used for personal safety on high voltage panels.

1. INSTALLATION

(Reference diagram on back side).

1. Mount the controller in a rain-tight protected location using #8 sheet metal screws; tighten to 14-16 in-lbs. DIN rail may also be used as alternate mounting. The suggested mounting area is 6 inches high and 8 inches wide, depth is 3 inches.
2. Mount the suction temperature sensor to the suction line after the evaporator. Connect the non-polarized sensor wires to "Coil Out 1" on the controller. **Maximum torque on screw terminals is 3.5 in-lbs.**
3. Mount the defrost termination sensor to the coil. Connect the non-polarized sensor wires to "Def 1" on the controller.
4. Mount the discharge air temperature sensor in the appropriate location in the case. Connect the non-polarized sensor wires to "Air 1" on the controller.
5. Mount the pressure transducer on the suction line near the suction temperature sensor, positioned at 12 o'clock.

Install the pressure transducer cable and connect the wires to "Pressure" on the controller. Black = "5V", White = "S", Green = "Gnd". Optional if the S3C Case Control already has a pressure transducer installed.


6. Connect the liquid line solenoid to "Sol/Pulse" on the controller.
7. Connect the Electronic Expansion Valve (EEV) to "Stepper Valve 1" on controller.
8. If an Electronic Evaporator Pressure Regulator (EEPR) is used, ensure side DIP switches 1, 2 and 3 are set ON (all down); see Figure 1.
9. Connect the EEPR to "Stepper Valve 2" on the controller.
10. Connect power to the Valve Module. **NOTE: Power will come from the S3C Case Control power supply.**


2. Press ▲▼ to scroll to the password (default is 1), press SET
3. Press SET when display shows **CASE**
4. Scroll to **uLuC** (valve configuration) and press SET
5. Scroll to **EP-t** (EPR type) and press SET
6. Change the steps to match the corresponding EEPR on the system, then press SET:
 - a. **2500**
 - b. **6386**
7. Press ESC three times to exit to main display

2. SETUP

The S3C Valve Module is set up and configured thru the S3C Case Control and S3C DM (display). On initial power up, the valve module will drive the EEV and EEPR closed. To ensure the valve module is configured properly to control an EEV on 'Stepper Valve 1' input and an EEPR on 'Stepper Valve 2' input, the following parameters must be set up thru the S3C DM. **NOTE: The Case Control, DM and Valve Module must be networked together as shown in the wiring diagram.**

Through the DM:

1. Press  icon on the front of the display



Temperature sensor should be mounted at either 4 or 8 o'clock, on a free-draining line.




Figure 1 - Side DIP Switches 1, 2, 3 ON (down) for EEPR control.

Sporlan S3C Case Control Installation and Operation Manual



For detailed instructions and part numbers, scan this QR code or go to www.sporlanonline.com/electronic-controls and download Bulletin 100-50-9.1




Diagram for reference only. Refer to input/output electrical ratings for all external connections.
 For safety information, see the Safety Guide at www.parker.com/safety or call 1-800-CPARKER.

⚠ Note: Use caution when working around high voltage components.

Visit www.sporlanonline.com for details on other Sporlan products such as sensors, transducers, and valves.

⚠ WARNING – USER RESPONSIBILITY

Failure or improper selection or improper use of the products described herein or related items can cause death, personal injury and property damage.

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

