



Multitech Gateway Installation Guide

SD-482 /11/2023



1. COMPONENTS


Ensure all components are available:

- A. Ethernet to Lightning Adapter
- B. Ethernet Cable
- C. Apple iPhone or iPad
- D. Sporlan Tech Check App


Download and install the Sporlan Tech Check App

to your iPhone/iPad by 1 of 3 methods:

- Click the following link:
[Sporlan Tech Check App](#).
- Scan the QR code at right using the iPhone/iPad camera.
- Search for 'Sporlan Tech Check' on the App Store



A



B



C




D

2 UPDATING GATEWAY FIRMWARE:



Unplug all ethernet cables from the Gateway

Connect one end of the Ethernet cable into the Gateway and the other end into the adapter, then plug the lighting connector into the phone.




3. iPhone Settings

1. From the iPhone Home Screen, go to **Settings** > **Ethernet**.
2. Under Interfaces tap **USB 10/100 LAN**.



3. IPHONE SETTINGS (continued)


3. Select **Configure IP**.



4. Change the "Configure IP" from Automatic to **Manual**.

Change the IP Address to **10.64.0.1**

Change the Subnet Mask to **255.0.0.0**




4. TECH CHECK APP


1. From the iPhone/iPad Home Screen, open the **Sporlan Tech Check App**.



2. and click on the **Gear icon**, then click on **Update Local Gateway**.



3. Choose the **Firmware Package**



4. When Firmware is finished uploading, unplug the adapter and plug the ethernet cable back into the Gateway.

⚠ WARNING – USER RESPONSIBILITY

Failure or improper selection or improper use of the products described herein or related items can cause death, personal injury and property damage.

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors.

To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

